

## Handling SOP – Thermal Coat US

### *Equipping Thermal Coat US with va-Q-gel*

#### **Step 1**

Provide Thermal Coat US and va-Q-gel to be used, unfold Thermal Coat US, then open hook-and-loop-fastener.



#### **Step 2**

Place va-Q-gel into pocket.

va-Q-tec's va-Q-gel is color-coded:

- +05G for +2°C to +8°C shipments: blue
- +22G for +15°C to +25°C shipments: green



---

### Step 3

---

Close hook-and-loop-fastener.



---

### Step 4

---

Repeat placing va-Q-gel into pockets. The following amount of va-Q-gel is required for the different heights of Thermal Coat US:

- 1.55m: 57 x va-Q-gel
- 1.05m: 45 x va-Q-gel
- 0.85m: 33 x va-Q-gel